

BLITZCLEAN CLEANROOM LAUNDRY BLEACH



FEATURES

- A liquid catalyzed oxygen bleach stabilized for longer shelf life
- Safe oxygen bleach specially formulated for polyester cotton linen
- Eliminates the need for anti-chlor that is use in rinses
- Eliminates excessive colour losses

APPLICATIONS

- In the break or suds cycle of a wash formula
- Can be added dry to the wheel at a concentration of 50 to 150 ml/100 lb dry load. (pH > 10.0 @ 70 - 80°C)
- Specially recommended for permanent press fabric items
- NOT recommended for use on heavily soiled items

Part Number	Description	Packaging
BZC/LD-BLEACH	Blitzclean Cleanroom Laundry Bleach	4 ltr/bt

BZC/LD-BLEACH	
Product Information	
Product Name	Blitzclean Cleanroom Laundry Bleach
Product Description	A colourless liquid catalyzed oxygen bleach
Ingredient	Stabilised Hydrogen Peroxide
Physical Data	
Appearance at 25°C	Liquid
Solubility in Water	Soluble
Volatile	Nil
pH Neat	1.7 +/- 0.4
Fire & Explosion Hazard Data	
Flash Point, °C	Nil
Flammability Limits in Air, % by Volume	Nil
Extinguish Media	Use CO ₂ or other dry chemicals on small fires. Use foam (alcohol, polymer or ordinary) and water spray for large fires.
Special Fire Fighting Procedure	Self-contained breathing apparatus and protective clothing should be worn in fighting fires involving chemicals
Unusual Fire & Explosion Hazards	Not known to Blitzclean chemicals
Health Hazard Data	
Effects of Prolonged	Contact with skin or eyes may cause temporary irritation
Emergency & First Aid Procedures	Flush eyes with copious amount of water for a minimum of 15 minutes. If irritation develops, consult a physician. If swallowed, drink plenty of water and consult a physician immediately
Stability & Reactivity Data	
Stability	Stable
Hazardous Polymerisation	Will not occur
Conditions to Avoid	Do not store with acids, alkali, strong oxidizing agent, reducing agents, accelerators and heavy metal compounds and organic products
Special Handling Information	
Ventilation	Local Exhaust: None should be needed Mechanical (general): Recommended
Protective Clothing	Rubber gloves or as required by your company
Eye Protection	Chemical worker goggles or as required by your company
Other Protective Equipment	Eye fountain and safety shower in work area
Spill, Leak & Disposal Procedures	
Action to Take for Spills	Place in a sealable container for subsequent disposal. Flush contaminated area with water
Disposal Method	Neutralize with acid or dilute with water and dispose as per your company procedure
Precautions To Be Taken in Handling & Storage	Store in well ventilated area at ambient temperature

NOTE:

This data is furnished gratuitously only for your investigation and independent verification. While the information is believed to be correct, Esco shall in no event be responsible for any damages whatsoever, directly or indirectly, resulting from the publication or use of or reliance upon data contained herein. No warranty, either expressed or implied, of merchantability, of fitness, or of any nature with respect to the product, or to the data, is made herein.

Blitzclean is a registered trademark of Esco®

Worldwide Headquarters · 21 Changi South Street 1, Singapore 486777 · Tel: +65 65420833 · Fax: +65 65426920
Email: mail@escoglobal.com · WWW Site: http://www.escoglobal.com · Last Revised Nov 2002